

Applied Wave Optics: Coherence

Reinhard Caspary

Version date: January 7, 2026



Except where otherwise noted, this document and its content are licensed under the Creative Commons Attribution-ShareAlike 4.0 International license.

Coherence

Origin: The Latin verb *cohaerere* = to stick together.

A wave field is called coherent, when it behaves identical at every place and time except of a certain phase shift. Coherence is the foundation of all **interference** phenomena.


The photons in a laser beam can be described as a stream of wave packets. Each initial seed photon was spontaneously emitted with an arbitrary phase. The subsequent amplification by **stimulated emission** keeps this phase.

There are two kinds of coherence

- ▶ **temporal coherence** along the optical axis z
- ▶ **spatial coherence** perpendicular to the axis in x and y direction

Coherence (cont.)

The average distance between the coherent sets of photons originating from the same seed is called **coherence length** L_c :



Superposition

The frequency and wavelength of all photons of a laser beam is (almost) the same.
Superposition of two plane waves from two sets with phase difference $\Delta\varphi$:

$$E = \frac{1}{2} \left[\left(E_1 + E_2 e^{i\Delta\varphi} \right) e^{i(\omega t - \mathbf{k}\mathbf{r})} + \left(E_1 + E_2 e^{-i\Delta\varphi} \right) e^{-i(\omega t - \mathbf{k}\mathbf{r})} \right]$$

The phase difference results in an interference term in the equation for the total intensity

$$\begin{aligned} I &= \frac{1}{2Z} |E|^2 \\ &= \frac{1}{2Z} (E_1^2 + E_2^2 + 2E_1 E_2 \cos \Delta\varphi) \\ &= I_1 + I_2 + 2\sqrt{I_1 I_2} \cos \Delta\varphi \end{aligned}$$

Coherence Factor

We introduce the coherence factor γ and the **contrast function** K :

$$K = \frac{2\sqrt{I_1 I_2}}{I_1 + I_2} \gamma$$

With the total incoherent intensity $I_0 = I_1 + I_2$ we get the interference equation

$$I = I_0(1 + K \cos \Delta\varphi)$$

The coherence factor allows to describe the general case of **partial coherence**

- ▶ incoherent: $\gamma = 0$
- ▶ partially coherent: $0 < \gamma < 1$
- ▶ coherent: $\gamma = 1$

Interference Pattern

The general phase shift between two waves may result from either a temporal offset τ and/or a spatial offset $\Delta \mathbf{r} = \mathbf{r}_2 - \mathbf{r}_1$:

$$\Delta\varphi = \omega\tau - k\Delta\mathbf{r}$$

For two waves with **equal intensity** $I_1 = I_2 = I_0/2$ the contrast function reduces to $K = \gamma$. The cosine function in the interference equation $I = I_0(1 + \gamma \cos \Delta\varphi)$ leads to the characteristic oscillation of interference patterns with local minima and maxima:

$$I_{min} = I_0(1 - \gamma)$$


$$I_{max} = I_0(1 + \gamma)$$

This allows to determine the local coherence factor from the measurement of the interference pattern $I(\tau, \Delta \mathbf{r})$:

$$\gamma = \frac{I_{max} - I_{min}}{I_{max} + I_{min}}$$

Coherence Volume

The self-superposition of an optical beam without temporal and spatial offset always results in a maximum of $\gamma = 1$ even for otherwise incoherent beams. Aside this point, the coherence factor decreases for increasing τ or Δr . The value $\gamma = 1/e$ defines a **coherence volume**. In axial direction its size is called **coherence length** L_c or **coherence time** $t_c = L_c/c$:



Correlation Function

The mathematical description of coherence uses the cross-correlation function:

$$\Gamma_{12}(\tau) = \langle E(\mathbf{r}_1, t) E^*(\mathbf{r}_2, t + \tau) \rangle = \lim_{T \rightarrow \infty} \frac{1}{T} \int_{-T/2}^{+T/2} E(\mathbf{r}_1, t) E^*(\mathbf{r}_2, t + \tau) dt = 2Z \sqrt{I_1 I_2} \gamma(\tau)$$

The spatio-temporal contrast function is defined as normalised cross-correlation:

$$K_{12}(\tau) = \left| \frac{2\Gamma_{12}(\tau)}{\Gamma_{11}(0) + \Gamma_{22}(0)} \right| = \frac{2\sqrt{I_1 I_2}}{I_1 + I_2} \gamma(\tau)$$

with the maxima of the auto-correlation functions

$$\Gamma_{11}(0) = 2Z I_1 \qquad \Gamma_{22}(0) = 2Z I_2$$

Correlation Function (cont.)

The case of pure temporal coherence is given for $\mathbf{r}_1 = \mathbf{r}_2$. The contrast function is a normalised auto-correlation function then:


$$K(\tau) = \left| \frac{\Gamma(\tau)}{\Gamma(0)} \right|$$

Pure spatial coherence is given for $\tau = 0$. The contrast function is the temporal maximum of the normalised cross-correlation function in this case:


$$K_{12} = \left| \frac{2\Gamma_{12}}{\Gamma_{11} + \Gamma_{22}} \right|$$

Temporal Coherence

A **Michelson interferometer** can be used to measure the coherence length of a laser:



Interference pattern of the interferometer:



Wiener-Khinchin Theorem

The Wiener-Khinchin theorem states that the **power spectral density** of a statistical process is identical to the Fourier transform of its **autocorrelation function**:

$$S(\omega) = \int_{-\infty}^{+\infty} \Gamma(\tau) e^{-i\omega\tau} d\tau$$

with the autocorrelation function


$$\Gamma(\tau) = \langle E(t)E^*(t + \tau) \rangle$$

From this follows the relationship between the spectral linewidth $\Delta\lambda$ of an optical beam and its coherence length L_c . Due to $\lambda = c/\nu$ this leads also to a simple relationship between the spectral bandwidth $\Delta\nu$ of a signal and the coherence time t_c :


$$L_c = \frac{\lambda^2}{\Delta\lambda} \qquad t_c = \frac{1}{\Delta\nu}$$

Spectral Bandwidth

Superposition of waves with three different frequencies around a centre frequency ν_0 and with the spectral bandwidth $\Delta\nu = 0.09 \nu_0$:



The respective contrast function $K(\tau) = |\Gamma(\tau)/\Gamma(0)|$ is




Spectral Bandwidth (cont.)

A list of optical radiation sources with increasing coherence:

Source	λ	$\Delta\lambda$	$\Delta\nu$	L_c	t_c
white light	400-800 nm	400 nm	400 THz	800 nm	2.5 fs
red LED	640 nm	40 nm	30 THz	10 μm	30 fs
FP diode laser	1.3 μm	4 nm	710 GHz	420 μm	1.4 ps
sodium-vapor lamp	589 nm	600 pm	500 GHz	600 μm	2 ps
HeNe laser	633 nm	2 pm	1.5 GHz	200 mm	670 ps
DFB diode laser	1.3 μm	100 fm	20 MHz	15 m	50 ns
stabilised HeNe laser	633 nm	200 am	150 kHz	2 km	7 μs
DFB fibre laser	1.55 μm	24 am	3 kHz	100 km	330 μs

Spatial Coherence

Young's **double slit experiment** can be used to measure the spatial coherence of a laser:



The maximum intensity I_{max} decreases with increasing slit distance and reaches $1/e$ of its single slit value for the spatial coherence length.

van Cittert–Zernike Theorem

The van Cittert–Zernike theorem states that the **angular intensity distribution** of a source is identical to the spatial Fourier transform of its **cross-correlation function**:

$$I(k_x, k_y) = \iint_{-\infty}^{+\infty} \Gamma_{12} e^{i(k_x x + k_y y)} dx dy$$

with the cross-correlation function

$$\Gamma_{12} = \langle E(\mathbf{r}_1) E^*(\mathbf{r}_2) \rangle$$


and $x = x_2 - x_1$ and $y = y_2 - y_1$. From this follows a condition for spatial coherence of a light source in the far field:

$$2d \sin \alpha \ll \lambda$$

with the source aperture width d and half exit angle α .

Coherence Filters

Generating coherent light from an incoherent source (incandescent bulb):



- ▶ **Incoherence** (no filter): many wavelengths, many directions
- ▶ **Spatially coherence** (pinhole): many wavelengths, single direction
- ▶ **Temporal coherence** (spectral filter): single wavelength, many directions
- ▶ **Full coherence** (both filters): single wavelength, single direction